

Case Displays



Industrial Display Case *New*

Includes 3 — 13" x 18" Clear Trays.

ITEM	DESCRIPTION
3503-1318	20½Wx17Dx22H
325-13-12	Replacement Tray



289



1019

Classic Euro Display Cases

Euro Front. Rear Door.
Includes 10" x 14" Clear Trays.

ITEM	DESCRIPTION
289	15½Wx13Dx11H-(2) 10x14 Trays
P255	15½Wx17Dx16¼H-(3) 10x14 Trays
1019	15½Wx12Dx7H-(1) 10x14 Tray
335-10-12	Replacement Tray



P255



Classic Display Case

Straight Front. One Door.
Includes 3 - 10" x 14" Clear Trays.

ITEM	DESCRIPTION
257	11Wx15½Dx17H
335-10-12	Replacement Tray



Classic Cake/Pie Case

Hexagon Front. Rear Door.
Includes 12" x 12" Shelves.

ITEM	DESCRIPTION
252	13Wx12½Dx21½H

