

Case Displays



a

a Bistro Bakery Case

Includes 3 Square Trays and 3 Rectangle Trays. Grated Shelves are Adjustable to Sit Straight or Slanted for Self-Serve or Attendant Serve.

ITEM	DESCRIPTION
3419-13	23¼Wx13½Dx24¾H
3047	Chalkboard Tents

Replacement Trays

3414-15	6½Wx11½Dx1H
3415-15	14Wx11½Dx1H

b Classic Large Bakery Case

Ships Truck Only! Self-Serve. Includes 6 — 13" x 18" Clear Trays.

ITEM	DESCRIPTION
288	27Wx23Dx28H
325-13-12	Replacement Tray



b

c Classic Attendant Serve Case

Includes 3 — 18" x 26" Clear Trays.

ITEM	DESCRIPTION
1202	27Wx20Dx20H
P235-12	Replacement Tray

d Classic Self-Serve Display Case

Includes 3 — 18" x 26" Clear Trays.

ITEM	DESCRIPTION
1202-S	27Wx20Dx20H
P235-12	Replacement Tray



c



d