

TABLETOP ACCESSORIES



Replacement Lids:
Lid No. 96091
Pack 12 doz./3#
.32 cu.ft.
SCC 847884

Shaker
Stainless Steel Top
No. 97052
2 oz./5.7 cl./57 ml.
H4½ T1½ B1½ D1½
6 doz./22# • .61 cu.ft.
SCC 143221



Winchester Shaker
Chrome Plated Brass Top
No. 70022
1½ oz./4.3 cl./43 ml.
H4½ T1 B2 D2
2 doz./7# • .38 cu.ft.
SCC 134656



Summit Shaker
Chrome Plated Metal Top
No. 75301
2¼ oz./6.7 cl./67 ml.
H5½ T¾ B1½ D1½
6 doz./21# • 1.18 cu.ft.
SCC 868506



Replacement Lids:
Lid No. 96021
Pack 12 doz./2#
.19 cu.ft.
SCC 092963

Shaker
Chrome Plated Plastic Top
No. 5221
1¼ oz./3.7 cl./37 ml.
H3½ T1½ B1½ D1¾
2 doz./9# • .25 cu.ft.
SCC 656738



Replacement Lids:
Lid No. 96021
Pack 12 doz./2#
.19 cu.ft.
SCC 092963

Shaker
Chrome Plated Plastic Top
No. 5037
1½ oz./4.4 cl./44 ml.
H4½ T1½ B1½ D2¼
2 doz./11# • .30 cu.ft.
SCC 334643



Cruet w/Stopper
No. 75305
6 oz./17.7 cl./177 ml.
H4¾ T1½ B1¾ D2¾
1 doz./7# • .44 cu.ft.
SCC 849086



3-pc. Cruet Set
No. 80371
H7½ T1½ B7 D7
6 sets/shipper/13# • 1.95 cu.ft.
SCC 849093



Black Server Lid
No. 96073
6 doz./5#
.27 cu.ft.
SCC 074624

Server
No. 5065
11½ oz./34.5 cl./345 ml.
H4¾ T2½ B2¾ D3¼
2 doz./8# • .94 cu.ft.
SCC 171866

